



Victron SmartShunt/BMV Settings to suit most LiFeP04 batteries

To locate these settings open the VictronConnect app > find your SmartShunt in the product list > open the settings menu> then select battery.

Battery Capacity	Battery bank Ah
Charged Voltage	14.0v, 28.2v & 56.4v (just below the absorption voltage from your charger)
Discharge Floor	20%
Tail Current	2%
Charged Detection Time	1m
Charge Efficiency Factor	98%
Peukert's Constant	1.02
Current Threshold	0.10A
Time-to-go averaging period	3m
Battery SOC on reset	Set to Keep SOC